



Which Battery Is Low?

Determining whether the system backup or a peripheral device battery is low.

A low battery warning is most often displayed as BAT, LOW BATT or SYSTEM LO BAT on the touchpad. The source of a low battery signal may be either the system backup battery, or it could be from a peripheral device, like a door sensor, smoke detector or glass break sensor.

[Replace a 12V 7Ah Battery](#)

[Replace a 7.2V Battery Pack](#)

[Replace a 6V 1.2Ah Battery](#)

Low System Battery

The system battery is a backup power supply. If you have experienced a recent power outage or if your system has been running on battery power rather than AC power for any other reason, it may just need to be recharged. Allow your system 48 hours to recharge the system battery. If the problem persists 48 hours after AC power has been restored, your battery should be replaced. Please refer to the [Identify Your System Battery](#) page to determine which battery your system uses.

Low Peripheral Battery

A low peripheral battery is usually indicated by a low battery message followed by a zone number. Peripheral batteries are not rechargeable and will need to be replaced. Please refer to the [Find the Right Peripheral Battery](#) page to determine which battery your device uses.

[Return to Top](#)